


User Manual – Post Processing Software For ARDC C-scan Data Files



Password Verification



3DEval
Version 3.0

3DEval-Login

User Name :


Password :

The image shows a login dialog box titled "3DEval-Login". It has a blue header bar with the title. Below the header, there is a small 3D terrain icon. To the right of the icon, there are two text input fields. The first is labeled "User Name :" and the second is labeled "Password :".


- When the 3DEval icon is double clicked a login dialog is opened as shown. The password is validated and the program is give administrator or user privileges accordingly.
- If it is the first time the program is run a message box is shown and the first user name will be given administrator privileges.



Updating User Info



A dialog box titled "Change Password" with a close button (X) in the top right corner. It contains three text input fields: "Enter Old Password:", "Enter New Password:", and "Confirm New Password:". Below the fields are two buttons: "Change Password" and "Close Window". At the bottom of the dialog is a larger button labeled "Administrator Tools".




A dialog box titled "Administrator Tools" with a table of users and two buttons: "Add User" and "Delete User". At the bottom is an "OK" button.

User Name	Type
adarsh	Admin.
bharat	Admin.
adarsh1	User

- Click on the tools-user Info to open the dialog box to change password.
- If the user has administrator privileges then another button called administrator tools is shown.
- A new dialog box is opened where users can be added or removed.

Opening Data Files




- To open a new data file, click on the open data file icon or go to <file> and select <open> menu.
- The descriptions about the icons on which the mouse is over is shown in the bottom of the main window.



3DEval
Version 1.2

Opening Data Files

- When <open> file is selected, the standard file open window will appear as shown below.
- Go to the directory that where the data files reside and select it by clicking on the open button.



Session Restore

- Select OK if you want to restore previous session.

Mar06C005.scn - 3D Eval

File View Tools Action Help

Side

Ultrasonic Image Processing

Do you want to reload previous session?

OK Cancel

Current Position

X 0
Y 0
Z 0
TT 0
Depth 0
Db 0

Color Scheme

7.75
7.16
6.56
5.97
5.38
4.78
4.19
3.59
3.00
2.41
1.81

Smooth Variation

Custom

Overview

Bounds

Data Offset
Start 0 End 0

Data Bounds



X	Min 0	Max 1392
Y	Min 2345	Max 4999
Z	Min 1000	Max 1000
TT	Min 55	Max 248
TT	Avg 152	SD 32.099
Db	Min 23	Max 92
Db	Avg 58	SD 11.608

Set as Default


500

Bottom Profile

Enhance Image






- When a data is loaded, the image is shown. To improve the image, click on the Enhance button on the tool bar or use the <Enhance> menu in the <View>.
- The interpolation scheme is used to densify the image and the picture resolution improves as shown on the left.
- Other windows and toolbar features will be described now.




dB and Tt representation

- By pressing either the Tt or the dB buttons on the tool bars, the travel time or the amplitude in dB can be imaged. At one time, only one of the feature can be displayed.





Filters



- Two types of image filters are provided to reduce speckle noise.
- The median filter with $n+1$, n , and $n-1$ algorithms.
- The mean filters of 1st and 2nd order.
- Inverse filter changes colors to inverse of the existing colors.
- Select <filters> from <view> menu.



Rotate & View

3D Projections – Side, Top Views



- The 3D data file is represented in the form of 3 orthographic projections. The main window represents the actual data that is analyzed while the top and the side views give the two other perspectives. The goal of the analysis must be to maximize the main window area while minimizing the other views.
- These can be turned **on or off** by using `<frames>` menu in the `<view>`.
- The views can be rotated using **rotate** button in the tool bar or by selecting `<rotate>` from the `<action>` menu.


Zoom and Pan




- Two types of zoom options are provided. The **boxed zoom** allows selection of any boxed area as shown in the left. The plain **magnifying glass icon** allows the user to magnify or de-magnify. To use it, (a) select the button, (b) move the cursor to the location of interest, (c) with the button depressed, drag the mouse to the right top corner of the screen to **zoom** and to the left bottom corner to **un-zoom**.
- To pan the image in the zoomed position, the hand button is used. Select the **hand** button and move the cursor to the region of interest and move freely, with the mouse button pressed, **to pan** the region.

Overview and Profile Windows

- The **overview window** provides the full view of the test part image with the zoomed region in inverse colors. To quick-zoom into any region, **click on that region** in the overview window and watch the image **quick-zoom** to that region.
- The **vertical and horizontal profiles** of the data (dB or Tt) is displayed as **side and bottom profile windows** respectively as shown in the figures in the right and bottom respectively.



Cursor Position Window




The image shows a software window titled "Current Position" with a close button in the top right corner. The window contains six rows of data, each with a label on the left and a text input field on the right. The values are: X: 2173, Y: 2933, Z: 248, TT: 748, Depth: 23.375, and Db: 26. To the right of the TT input field is a small blue square, and to the right of the Db input field is a small red square.

Label	Value	Color
X	2173	
Y	2933	
Z	248	
TT	748	Blue
Depth	23.375	
Db	26	Red

- The X, Y, and Z values in mm is displayed in the Current Position Window. The cursor must be in the main window for this.
- The corresponding TT and DB values are also displayed along with the corresponding colors.
- The Depth in mm is also shown.



Refresh and Default & Undo




Zoomed View

Undo

Default View

- The **refresh** button in the tool bar will **redraw** the views and windows.
- You can undo any action by using the **undo** button.
- The **default** button will make the views go back to the **full image** from a rotated or zoomed image.
- All controls are available under **<View>** menu.

Data Bounds Window



The screenshot shows a window titled "Bounds" with a close button in the top right corner. It contains two main sections: "Data Offset" and "Data Bounds".

Data Offset: This section has two input fields: "Start" with the value "0" and "End" with the value "0".




Data Bounds: This section contains a table of input fields for various parameters:

X	Min	2070	Max	2290
Y	Min	2900	Max	3200
Z	Min	248	Max	248
TT	Min	338	Max	1247
TT	Avg	793	SD	151.46
Db	Min	3	Max	22
Db	Avg	13	SD	3.3188

At the bottom of the window is a button labeled "Set as Default".


- **Data Offset** – Allows the user to neglect points that are not useful either in the beginning or at the end of the data file. Just enter the number of points not to be considered.
- **The Data Bounds** - provides the size of the scan, the TT and DB **average (Avg.)** and **Standard Deviation (SD)** values are indicated for the entire data set.
- The **Min and Max values** are used to determine the color scale. These values can be manually changed by operator by **entering the required value** and pressing the button **<Set as Default>**
- For instance, if the color scale must represent **1 dB increments**, then range must be 10 dB since the color scales are divided into 10 bins, i.e.. the difference between Max and Min must be 10 dB. If the scale must be in **2 dB increments**, the difference must be 20 dB, and so forth.

Color Scales and Histogram




- The **Color Scheme window** has two slider controls. The **<Left Slider>** controls the scale by moving it higher or lower. The **<Right Slider>** controls the range of the scale.
- The **10 Color Scale** near the sliders can be selected by the drop-down selector. Several standard color schemes are provided. For selecting a custom scale, choose **<Custom>**. This prompts the **Custom Color pop-window**. Here each color can be chosen by clicking on the window and selecting from the standard color palette. If the **<smooth>** box is checked, the color scale is gradual and not discrete. This works only on standard color schemes.
- The **Histogram** of the data is shown in the right.
- The color scale range can also be controlled by manually entering the values in the **Min** and **Max** boxes in the **bounds window** and pressing **<Set as Default>**


Re-size Main Window



- In order to either increase or decrease main window, move the cursor to the **right-bottom** of the main window, press and **drag up** to decrease window size and **down** to increase the size.
- All other windows will re-position accordingly.
- The views and the profiles windows will also automatically resize and reposition accordingly.
- Some of the **tool bar buttons** can go out of range if the size is reduced less than default size. If so, use the **menu**.





Distance/Size Measurement





- Use **<Distance>** button to **measure linear distances/sizes** in the images in mm.
- Select **<Distance>** button or from **<Tools>** menu.
- Then **Click** any point on the main window image.
- Then **Click** again on any other point.
- The **distance/size** between the two selected points is provided in the bottom of the window in mm.

Analyse – Select Grid.





- The **Analyse** button in the tool bar is used to **search, mark, and size flaws** and other features such as **bolt holes**.
- Press the **Analyse** button or select **<Analyse>** from the **<Tools>** menu.
- The main window will show a 4x4 **Grid** and the color will change to a **3 color scale**.
- **Click** on any of the Grids to **Zoom** into this grid as shown here on the left.
- Pressing **<space-bar>** key will **switch** the Zoomed area from one Grid to the next adjacent Grid.
- It is not necessary to select a Grid. The entire window can be analysed. Pressing **<shift>** and **Click** will take you to unzoomed position.
- **Zoom, Pan, dB, Tt** buttons are deactivated during this operation.

Analyse – Threshold Flaws




- The Data Analysis window is used to threshold flaws.
- The middle color represents flaw values.
- The extreme colors represent non-flaw values.
- Change Min and Max range values from the Color Scheme or Bounds windows such that the value in the flawed region is in within the middle range.
- Move the upper and lower sliders in the Data Analysis Window such that the flaw is shaded in the middle color as shown in the left.
- The default colors are Green for Flaw and Blue and Red for extremes. These colors can be re-selected by clicking on the color boxes in the Data Analysis Window and selecting from the Color Palette.

Analyse – Select Flaws



- Once the flaw is thresholded such that the middle color fills the flaw region, the flaw must be isolated and selected.
- Move the cursor to any point within the flaw region.
- While pressing the **<Ctrl>** button, press the **click** button in the mouse.
- Using a unique “**water flow algorithm**”, the defect region will be isolated and the rest of the region will take the bottom extreme color as shown in the left.
- If the cursor is not on a pixel that is in the middle color region, an error window appears. In such a case, Press OK and reposition the cursor and again **<ctrl>click**.

Analyse – Save Flaws/Holes



Flaw-Hole Detection


Type
 Flaw Hole

Properties

	Min	Max	Cen
X	2192	2207	2198
Y	2916	2930	2922
Z	248	248	248
Max Length	16.1245		
Area	134.336		
Avg. Depth	30.5655		

- Once the flaw is isolated and selected, the flaw information must be saved.
- The **Flaw-Hole Selection Window** shown on the left will pop up.
- The properties of the **Flaw/Hole** is shown. The **Min**, **Max**, and **Centroid** of the flaws are noted in all three axes.
- The **Maximum Length** of the flaw, the **area** and the **average depth** of the flaw are also calculated and displayed.
- The information can be categorized as a flaw or a hole (for all designed part feature).
- Click **<OK>** to accept for **SAVING** information or **<Cancel>** to proceed without saving.
- If **<OK>** is pressed, the flaw information is stored in a data file that ends in ***.flw**. This allows the user to take breaks and log off and **resume analysis**. Also, if the program crashes, the flaws selected are saved.

View Flaws



- The flaws can be view in the Summary window by selecting **<View Flaws>** in the **<Tools>** menu.
- This view combines report features and the flaw database.
- The **Select Flaw** menu allows the user to view the properties of each flaw. The **<up-down-arrow>** buttons allow scrolling from one flaw to another. A maximum of 30 flaws can be chosen.
- The chosen flaw/hole is highlighted by **color**.
- Use **<Delete Flaw>** button to **remove any flaw/hole** from database.

Acceptance Standards

Acceptance Standards

Monolithic Part | Corner Radii of Monolithic Part | Honeycomb

Select Grade
Grade A

Maximum Area of defect (mm²) A Max 25

Maximum Length of defect (mm) L Max 8

Minimum Significant defect size (mm) S 3

Minimum Spacing of defects (n*LMax) D 6

Max Cumulative Area in 200 mm dia circle (mm²) 220


Max Cumulative Area in 200 mm length (%) a% 2

Proximity of Delamination Boundary to edge (mm) P 10

Restore Default | Set Values | OK

- The ADS-32 standards can be viewed using the [<View Tables>](#) in the [<Tools>](#) menu.
- The **Part Type** can be selected by using the appropriate tab and the **Grade** can be selected using drop-down menus.
- New values can be entered using [<Set Values>](#).
- The ADS-32 standards can be restored using [<Restore Default>](#) button.

Go/No-Go Evaluation Report



- The **GO/NO-GO report** can be viewed in the Summary window by selecting **<View Flaws>** in the **<Tools>** menu.
- The TT and the DB views are represented. The flaw database is also included.
- A window is provided for entering **comments** from the operator. Click and type.
- The window on the right represents all relevant **scan parameters**.
- Depending on the **Part Type Selected**, the Evaluation Criteria are displaced.
- To Evaluate the **GO/NOGO**, press **<Evaluate>** button. Make sure that appropriate Part Type and Grade has been selected using **<view tables>**
- After evaluation click on the **<Report>** button to generate a word report.

Go/No-go Analysis

- The Evaluate function will compare the flaw dimensions with the ADS-32 and provide GO (GREEN COLOR) and NOGO (RED COLOR) indication.
- For details on the failures, Click on the RED boxes to get the defects or group of defects that failed the Criteria.
- You can change the angle of the part to analyse the flaws in another line.
- The part type and grade can be changed by using the tables button.

Select Flaw

Monolithic Part Grade A

Property	Value	Color
Maximum Area of defect (mm ²)	221.79	Red
Maximum Length of defect (mm)	42.0119	Red
Minimum Spacing of defects (mm)	34.4384	Red
Max Cumulative Area in 200 mm dia circle (mm ²)	578.74	Red
Max Cumulative Area in 200 mm length (%) a%	10.3229	Red
Proximity of Delamination Boundary to edge (mm)	33.7259	Green


Angle: 30

Property	Min	Max	Cen
X	0	0	0
Y	0	0	0
Z	0	0	0

Max Length: 0
Area: 0
Avg Depth: 0
Type: Hole

Delete Flaw Refresh Save Print Tables Evaluate OK


Reference File Comparison




- The option to load and compare a **reference data file** is provided.
- Select **<open reference file>** from the **<file>** menu and select the reference data file.
- This opens a new window called reference file and any operation such as **Zoom, Pan, Color Change, etc.**, to the main window is reflected here.
- To **Plot the difference** between the main window data file and the reference file, select **<Plot Difference>**, in the **<Reference File>** menu under **<View>**.
- For Plot Difference to work well, the **data file** and the **reference file** must be collected using **identical settings**.

Nudge

- Use this to nudge the image left, right, up or down.
- Use the center button to restore the original position.
- Use the text box to change the value of nudge.





Some General Features

- All windows can be closed either by clicking on the **x** box on the right top corner or by **un-checking the frames/window/toolbar** on the menu.
- To open back the windows, go to the the menu and **select the frame/window/toolbar** required.
- While analysing a data file, to **open another file**, proceed with open file operation and click **<OK>** button when prompted.
- For changing some of the **color schemes of the window borders**, etc., go to the **<Control Panel>** in the **WINDOWS** and select **<Display Icon>** and make changes in the **<Appearance>** tab.